OPERATION AND MAINTENANCE GUIDES



promaxplastics.co.nz

O&M For:	XP1000120
Date:	July 2022
Code:	XP1000120
Description:	Promax Header Tank 120 Ltr
Product Warranty:	5 years

SPECIFICATIONS

	Capacity (L)	Diameter (mm)	Height (mm)	Weight (kg)	Manhole Dia (mm)
	120	660	510	5	250
Standard	Includes 1x 20mm Outlets. Complies with: • AS/NZS 4020, AS/NZS 2070 (INT) Potable Water Standards				
Uses	Portable Water StorageRetention/Detention Stormwater Management				
Statement	In line with today's focus on Ecologically Sustained Development, Green Building Initiatives and 5 Star Ratings, Promax is committed to supplying quality Liquid Storage and Handling Solutions. Promax Plastics confirms that if these tanks are installed according to Good Management practices set out in the Promax Installation Guides, they will perform as stated throughout their intended life.				

MAINTENANCE

Description	Action	Frequency
Tank Stability	Tank must remain level, foundation must not become eroded	Monthly
Tank Lid	Remains securely fitted	Bi-Monthly
Inlet/Outlet Fitting	Remains securely fitted with no leakage	Bi-Monthly
Pump	Check Pump, if fitted, for inlet screen blockages	Bi-Monthly

Please note: Entry into this tank is at owners risk.



Promax Engineered Plastics Limited PO Box 749, Kerikeri 0245, New Zealand E: sales@promaxplastics.co.nz

OPERATION AND MAINTENANCE GUIDES



promaxplastics.co.nz

Responsibility:	The owner/s are responsible for maintenance of the tank.
Post Storm Inspection:	Following a storm event it is recommended that a full tank inspection is carried out, please refer the maintenance section for guidelines on this.
Debris removal programme:	If debris is identified in either a regular maintenance check or post storm inspection it is recommended that this is removed by a professional stormwater maintenance provider.

MAINTENANCE RECORDS

Date	Comments	Completed



Promax Engineered Plastics Limited PO Box 749, Kerikeri 0245, New Zealand T: 0800 77 66 29 E: sales@promaxplastics.co.nz